

## User Quick Setup Manual

### 1. Open the package and check the appearance and accessories

### 2. Please press the button to turn the scanner on

### 3. Connecting and transmitting schemes

Attention please: When the scanner turns on, the blue colored light will flash and then turn off. After beeps, it can be configured to 2.4G mode (single blue colored light flashes) and Bluetooth mode (two blue colored lights flash alternately). The blue colored light is always on after connect successfully. After booting, it will try to connect according to the connection method before shut down. For example, before the scanner turns off, the scanner and the mobile phone Bluetooth pair successfully. After rebooting, the scanner will automatically connect to the mobile phone while its Bluetooth on.

#### 3.1 Bluetooth mode

If the terminal device (exp: mobile phone, computer) comes with Bluetooth and turns on, the scanner can scan the following barcodes in sequence to connect with it. If connect successfully, the blue colored indicator is on. (Note: For the meaning of indicator refer to part 8).



Enter Settings



Bluetooth HID Mode



Searching



Exit Settings

#### 3.2 2.4G mode

After plugging Dongle into the computer and the computer identifying Dongle successfully, scan “Enter Settings”, then scan “2.4G Mode” and then scan “Connect Dongle” to pair. After connect successfully and the blue colored indicator lights on, please scan “Exit Settings”. (Note: For the meaning of indicator refer to part 8).



Enter settings



2.4G Mode



Connect Dongle



Exit Settings

### 4. Active Factory Defaults

Scanning the “Active Factory Defaults” barcode below will return the device to its factory configuration. This barcode does not change the connection and transmission method.



Active Factory Defaults

### 5. Function configuration

#### 5.1 Configure carriage return (CR),line feed (LF)



Enter settings



Add CR suffix



Add LF suffix



Add CR+LF suffix



Clear CR+LF suffix



Exit Settings

### 6. Power down method

The scanner be normally connected but not in use will automatically shut down after about 5 minutes. When you do not use the scanner device, you can scan the following barcodes in sequence to shut down the scanning device directly.



Enter Settings



Power Down

## 7. Operation mode

The scanner has two operation modes, one is “**Normal mode**”, and the other is “**inventory mode**”. When you would like to release data which stored, please scan “**Release Data**”. Attention: When you have released the stored data and the scanner beeps, please scan “**Clear Data**” because the device does not delete the last stored data automatically.

### 7.1 Enter the settings of the working mode



Enter Settings

### 7.2 Selection mode



Normal Mode



Inventory Mode

### 7.3 Inventory mode



Total Counts



Release Data



Clear Data

## 8. Meaning of indicator status & beeper tone

The two blue colored lights flash alternately: The scanner is in

pairing mode and is trying to connect to the Bluetooth of the terminal device.

The blue colored light single flashes: The scanner is in 2.4G mode and is trying to pair with the Dongle.

The blue colored light always on: The scanner connects to the terminal device successfully.

Beep three times: The configuration barcode is configured successfully.

Beep one time: The connection to the mobile phone, computer with Bluetooth is successful. The barcode transmission is successful.

The green colored light and the blue colored light flash in sequence: The decoding is successful.

## 9. Common Questions

### 9.1 What to do if cannot connect to Bluetooth?

Make sure the phone is android 3.0 or above, it can be connected directly.

### 9.2 Why part of the barcodes cannot scan?

Factory defaults settings are closed due to part of barcodes are not commonly used. It can normally scan if you just open the corresponding barcode settings. If you do not know the corresponding barcode type, please contact the supplier.

### 9.3 Why barcodes cannot be uploaded to a computer or phone?

- Make sure barcode scanner has been successfully paired. If yes, LED display is blue.
- Pls check whether inventory function is opened. In inventory mode, barcode will not automatically upload. You need to manually scan the corresponding barcode to upload.
- Change to normal mode, you can scan while uploading.

### 9.4 How to do if computer or mobile phone cannot find the Bluetooth scanner?

To confirm whether the selected communication mode is Bluetooth HID mode. If it is other communication mode, pls contact the supplier for relevant testing tools.

### 9.5 Bluetooth scanner has been connected with the phone or computer before, how to pair with the phone or computer again?

Select the paired Bluetooth in the Bluetooth search interface, and then search connection and pair again.

### 9.6 How to do if unable to automatically connect after Re-plug the Bluetooth adapter or restart the phone?

Make sure the terminal device (exp: computer or mobile phone) is not connected with other Bluetooth devices and the Bluetooth scanner does not paired with other devices, please simply re-start the Bluetooth scanner and it can be automatically connected.

### 9.7 Why unable to connect after switch to other communication mode?

Remove the paired Bluetooth device after switching mode and then re-connect the pairing to connect the device.

### 9.8 How to change more scan settings?

Please contact the supplier directly.

## 10. Technical supporting

If this manual doesn't solve your problem, please contact your supplier.